



Chapter 4

On-Chip Subsystems Interface

FIPSOC
User's Manual

On-Chip Subsystems Interface

Overview

The Field Programmable System On Chip (FIPSOC) constitutes a new concept in system integration. It provides the user with the possibility of integrating a microprocessor core along with programmable digital and analog cells within the same integrated circuit. This chip can be considered as a large granularity FPGA with a FPAA (Field Programmable Analog Array) and a built-in microprocessor core that does not only act as a general purpose processing element, but also configures the programmable cells and their interconnections. Therefore, there is a strong interaction between hardware and software as long as signal values and configuration data within the programmable cells are accessible from microprocessor programs.

This chapter describes the communication interface between the built-in 8051 and the programmable blocks integrated on the FIPSOC chip. The mP8051 has two functions: firstly, it configures each of the on-chip subsystems; secondly, after the programmable blocks are configured, it is used as general purpose microprocessor. Thus, the interface circuitry among the different blocks has been optimized.

Both configuration and data exchange is made through the memory map of the built-in 8051 core. This enhanced memory organization keeps, by default, the map distribution of the original 8051. New registers included in the SFR area of the 8051 have been added for system and memory organization control purposes. Manipulating these registers, the memory organization of the processor may dynamically change.

With accurate programming, the mP8051 is able to configure and control the programmable blocks through its internal and external memory and SFR areas.

The Regular Configuration Memory of the Programmable Logic Block has a double function:

firstly, it is used as a buffer memory for the configuration registers of the DMC (new configuration is not updated until a transfer command is sent); secondly, it can be used as general purpose on-chip memory, so no external memory is needed.

1. 8051 Memory Organization

The memory map of the on-chip mP8051 keeps, by default, the memory organization of the original 8051. That is, it has a separate address space for Program Memory and Data Memory, distributed in the following four addresses spaces:

- Up to 64 Kbytes of Program Memory,
- Up to 64 Kbytes of external Data Memory,
- 256 bytes of internal Data Memory,
- 128 bytes of Special Function Registers area.

On the FIPSOC chip, two memory areas have been added, overlapped with the original memory areas, with the purpose of accessing to the different configuration memories and control registers of the on-chip peripherals of the 8051. These locations, whose mapping is configured by Special Function Registers, are mapped in the following two spaces:

- 64 bytes of internal data memory, called buffer access area,
- Up to 16 Kbytes memory mapped on the lower external Data Memory (depending on device)

1.1. Program Memory

The Program Memory of the on-chip mP8051 consists of an internal and an external space (see figure 1.1). 512 bytes of Program Memory resides on-chip (dedicated to the FIPSOC's Boot Program). The program memory can be externally expanded up to 64 Kbytes. The internal memory may be disabled; in that case, the 8051 fetches all instructions from the external program memory.




Fig. 1.1: Program Memory Address Space

256 bytes random access memory (*auxiliary memory*) is provided in the upper addresses space and may be simultaneously mapped in both program and data memories. If this memory is enabled, location \$FF00 through \$FFFF are fetched from it (see Microprocessor Document for further information).




Fig. 1.2: Data Memory / SFR Address Spaces

1.2. Data Memory

The Data Memory address space consists of an internal and external memory portion.

- **Internal Memory:** It is divided into four physically separated blocks (original 8051 internal memory is only divided into three blocks): the lower 128 bytes

of RAM, the upper 128 bytes RAM area, 128 bytes of special function register (SFR) area and 64 bytes (located in \$30 through \$6F) of the buffer access space (figure 1.2).

Both SFR area–upper RAM and lower RAM–buffer access share the same addresses locations, so they must be accessed in different ways:

- SFR area and upper RAM are accessed through different addressing modes (direct and indirect addressing, respectively)
- The scratch pad area located in positions \$30 through \$6F may be disabled in order to access to the buffer access area (only one of these two memories may be enabled at a time)

The lower 128 bytes are grouped in four addresses space (as shown in figure 1.3):

- Four General Purpose Registers banks (\$00 through \$1F),
- Next 16 bytes (\$20 through \$2F) contains 128 directly addressable bits,
- Location \$30 through \$6F can be used either as a scratch pad area or as buffer access area (as shown below)
- Location \$70 through \$7F can be used as a scratch pad area.




Fig. 1.3: Lower portion of the Internal Data Memory

F8	ROWL (00)	ROWH (00)	COLL (00)	COLH (00)	RG1 (00)	RG2 (00)	RGTX (00)	outCOMP (0X)	FF
F0	B* (00)	CKCONF (60)	CKCNTL (00)	CKCNTH (00)	CKDMC2 (00)	CKDMC1 (00)	CKANA (00)	CK8051 (6F)	F7
E8	DBG2L (00)	DBG2H (00)	DBG3L (00)	DBG3H (00)	DBG4L (00)	DBG4H (00)	DBG5L (00)	DBG5H (00)	EF
E0	ACC* (00)	ANAST (0X)	DBGCNF (00)	DBGMSK (00)	DBG0L (00)	DBG0H (00)	DBG1L (00)	DBG1H (00)	E7
D8	DANA1 (XX)	DANA2 (XX)	DANA3 (XX)	DANA4 (XX)	DANA5 (XX)	DANA6 (XX)	DANA7 (XX)	DANA8 (XX)	DF
D0	PSW* (00)								D7
C8									CF
C0	EIMR0 (00)	EIMR1 (00)	SGNI0 (00)	SGNI1 (00)	IRS (XX)	IRSCKDB (00xxxxxx)			C7
B8	IP* (xxx00000)				VHW4L (00)	VHW4H (00)	VANAL (00)	VANAH (00)	BF
B0	PRTD* (FF)				VDBGH (00)	VDBGH (00)	VHW3L (00)	VHW3H (00)	B7
A8	IE* (0xx00000)				VCLKL (00)	VCLKH (00)	VHW2L (00)	VHW2H (00)	AF
A0	PRTC* (FF)				VPLL (00)	VPLH (00)	VHW1L (00)	VHW1H (00)	A7
98	SCON* (00)	SBUF (XX)	WDOG (00)	RG3 (02***)	I2CREG (**)	BTREG (**)	DDRGF (FF)	CMBUF (XX)	9F
90	PRTB* (FF)								97
88	TCON* (00)	TMOD (00)	TL0 (00)	TL1 (00)	TH0 (00)	TH1 (00)			8F
80	PRTA* (FF)	SP (07)	DPL (00)	DPH (00)				PCON (0xxx0000)	87

* bit addressable

(Reset values of the SFRs)

SFRs in grey only in FIPSOs

** Reset value depends on general port values

*** It depends on FIPSOs version

Table 1.1: Special Function Registers map (SFR)

- **External Memory:** There can be up to 64 Kbytes of external data memory. Its addresses can be either 2 or 1 byte wide (using the 16 bit data pointer or an 8-bit general-purpose register). Refer to Microprocessor Document for detailed descriptions.

The external data memory address space is divided into four different areas (as shown in figure 1.4):

- Up to 64 Kbytes of external data memory area (this memory is represented in four regions in figure 1.4)
- Lower 16 Kbytes (12 Kbytes, 6 Kbytes or 4Kbytes, depending on device version) can also be used for mapping on-chip subsystems

configuration memory. If this memory is enabled, lower 16 Kbytes (12, 6 or 4 Kbytes) of the external memory area are not available (some bits of a special register will select the active area).

- Next 256 bytes for hardware probing and writing of the output of the DMCs. Only one of these two memories may be enabled at a time (that is, the 256 hardware memory or external data memory)
- Upper 256 bytes may be internally mapped through the *auxiliary memory*. Note that if the *auxiliary memory* is enabled both upper 256

locations of data and program memories coincide.

1.3. General Purpose Registers

The lower 32 positions of the internal RAM are grouped into four banks of 8 registers. Only one of the banks may be enabled at a time (two bits of PSW register are used to select the active bank). For indirect addressing, two of them are used as pointer or index registers.




Fig. 1.4: External Data Memory Space

1.4. Special Function Registers (SFR)

The SFR area is located in the upper 128 bytes of the internal memory. It has two important functions: Firstly, all CPU registers reside in this area (excepting PC and GPR banks). Secondly, a number of registers (not included in the SFR area of the original 8051) constitute the interface between the mP8051 and all the on-chip subsystems.

SFR, which are located in addresses which are multiple of eight, are both byte- and bit-addressable. All SFR can be accessed by direct addressing only (see Table 1.1).

Note that not all of the addresses are occupied. Unoccupied addresses are not implemented on the chip (and the may be used in future). Read access to these addresses will return random data; write accesses will be ignored.

2. Subsystems Interface

The configuration and control of the subsystems that are included in the FIPSOC chip are realized through accesses to locations of the different memories of the mP8051. Some memory locations of the SFR area have

been reserved for system configuration and general-purpose control.

The subsystems and the memory used for configuration are listed below:

- The programmable blocks (CAB and PL block) are configured (and accessed) using special function registers and data memory (both internal and external) of the 8051 memory organization. Thus, the configuration and data transfer of these blocks is made through positions located in both internal and external memories.

- Programmable Logic Block:** Either internal or external memory locations may be used to configure, control and transfer data. In particular, both configuration memory and hardware outputs of the DMC are mapped in both internal (buffer access) and external; LUT memory data in DMCs can be accessed through internal memory only.

- Configurable Analog Block (CAB):** The configuration of the block is made through the buffer access area only; Data transfer is made using memory locations of the SFR area.

- Other subsystems are configured and controlled with special function registers only. These blocks, not described here, are the Clock Generation Block (CGB), Interrupt Service Block, Serial Communication Block, Debugger Block, Watchdog Block and other 8051 peripherals systems (Parallel & Serial I/O, Timers, etc.)

2.1. External Memory

Locations \$0000 through \$17FF of the external memory are used to map the configuration memory of the PL block. Next 256 bytes are used to probe hardware outputs of the DMCs. Table 2.1. shows the external memory distribution for different FIPSOC models.

All these memory areas may be independently and simultaneously mapped. External memory can always be disabled. When a particular memory block is disabled, its memory space becomes automatically available for external use (out of the chip through the external bus).

For example, the following memory usage can be configured:

- ✓ both *auxiliary memory* and *hardware probing registers area* may be mapped, leaving the lower 16 Kbytes as the original external data memory.
- ✓ the whole 64K of the external data memory may be mapped
- ✓ Region 1, 2 and 4 of the original external data memory have been disabled in order to access to

PL Configuration Memory, HW Probing Area and Auxiliary Memory, respectively

Setting or clearing the values of the corresponding bits in the system control registers (see later in the document), the configuration of the memory can be changed. This re-configuration can be made dynamically; that is, non-reset between different configurations are needed.

2.2. Buffer Access

The Data Buffer Area is located in \$30 through \$6F of the internal data memory of the 8051. By default, this portion of memory is not mapped, and the original memory organization is obtained (see figure 1.3). When buffer access area is enabled (first scratch pad area is disabled because only one of them may be active at a time), memories and registers from several different blocks throughout the FIPSOC chip can be accessed, depending on the access mode (these modes will be described in detail later in the document):

- **PL Block Regular Configuration Memory:** Locations \$30 to \$4F map buffer context #0 (\$50 to \$6F for buffer context #1). A write operation on any of these locations writes data to all the DMCs selected with the row and column mask registers (mapped in the SFR area). A read operation should only be done with one DMC selected, otherwise the internal priority control circuit would select only the one with the bigger column and mask number. Configuration memory for the IO cells and CAB-DMCs routing resources can also be selected setting the corresponding bits included in the row and column mask registers.
- **PL Block LUT data memory:** Locations \$38 to \$3F map nibbles 0 to 7 of the Low Tile of the DMC selected with the mask registers. Locations \$40 to \$47 map the nibbles 0 to 7 of the High Tile of the DMC selected to the mask registers. In both cases, the lowest nibble is always used. Locations \$48 to \$4F map nibbles 0 to 7 of both tiles, using the four most significant bits of each location for the nibble corresponding to the High tile and the four least significant bits for the Low Tile. Several DMCs can be selected for multiple write operations, while only one for reading (the priority circuit works like in the Regular Configuration Memory mode). Locations \$30 to \$37 and \$50 to \$6F are unused.
- **PL Block Hardware Probing memory:** This access mode is intended to provide a fast way to probe hardware signals in real time, both sequential and combinational. Only the outputs of a Chip Quarter are mapped, so the appropriate Chip Quarter must be selected first with the Mapping Control Registers (mapped in the SFR area)

- **PL Block Hardware Writing mode:** This access mode is intended to provide a fast way to write in the flip-flops of the sequential part of the DMCs in real time. Only the DMCs of a Chip Quarter are mapped, so the appropriate Chip Quarter must be selected first with the Mapping Control
- **CAB Configuration memory:** CAB Configuration is done by writing in non-buffered conventional RAM memory. No multicontext operation is allowed for the CAB. In this mode, the buffer directly maps the whole CAB configuration memory for read and write access. No context transfer command is needed like for buffered multicontext configuration memory (DMCs and IOs).

Note that the regular configuration memory registers and the hardware probing and flip-flop writing memory locations may be also mapped in the external memory. These access modes are independently configured and may be used at the same time. **These memory locations cannot be reached** from any program running from the programmable logic configuration memory (due to timing scheduling conflict)

The data in the *Regular Configuration* can be used either for general purpose data or for configuring the Programmable Logic Block. Data is stored in the memory cells until a transfer command is sent (see PL Block Document for further information).

2.3. Extended SFR map

The new special function registers added to the original SFR map of the 8051 are dedicated to control, configure and data transfer purpose. Only 18 of them are related to the programmable blocks interface and the system mapping control. In particular, SFR may be grouped as follows:

- **System Mapping Control Registers:** These registers are used by FIPSOC for memory organization control and buffer access modes. They include:
 - a) Row and Column mask (two 16-bit registers -*ROW* and *COL*- and one nibble of general control register -*RG2*[7:4]-),
 - b) General Control registers (three locations, *RG1*, *RG2* and *RG3*),
 - c) Transfer command (one register, *RGTX*).
- **Analog Control Registers:** Ten registers are used for (digital) data transmission with the CAB. Input registers for the DACs are written here and output registers from the ADCs and comparators are read (*DANA1* through *DANA8* for DACs/ADCs operations and *outCOMP* for comparators reading). Control commands for this block are also issued writing to one of these registers (*ANAST*).

The new SFR map is completed with control registers of the on-chip subsystems (described in their corresponding documents).




Fig. 2.1: Fast access bus interface

ports of 8 bits). Due to the fact that FIPSOC integrates some external peripherals on-chip, not all the 4 ports are accessible from the external system. In particular, port 2 and port 3 of the 8051 have been used for internal communication purposes (see figure 2.1)

- Port 2 is utilized by the system for accesses to external memories.
 - ✓ Only output direction is available (normally used as high byte address),
 - ✓ Input direction of Port 2 has been dedicated for the communication between the PL block and the 8051 (PL→8051 direction),
- Port 3 has been reserved for internal use only (except data memory strobes and RX / TX of the serial interface).
 - ✓ Output of bits 0 to 5 are dedicated for the communication with the PL block (8051→PL direction),
 - ✓ Output 0 enables the TX lines of the serial interface
 - ✓ Bits 2 and 3 (inputs) are reserved to interrupt signals,
 - ✓ Bits 4 and 5 (inputs) are reserved for external timer purpose, and come from the PL block.

(see Microprocessor Document for further information)

2.4. Port Access

The original 8051 has 32 bi-directional and individually addressable I/O lines (grouped into four

8x8	12x8	16x12	16x16	
\$0000 to \$0FFF	\$0000 to \$17FF	\$0000 to \$2FFF	\$0000 to \$3FFF	<i>Regular Configuration Memory</i>
\$1000 to \$10FF	\$1800 to \$18FF	\$3000 to \$30FF	\$4000 to \$40FF	<i>Hardware Probing Registers</i>
\$FF00 to \$FFFF	\$FF00 to \$FFFF	\$FF00 to \$FFFF	\$FF00 to \$FFFF	<i>Auxiliary Memory</i>

Table 2.1: External memory distribution for different FIPSOC models

3. System Mapping Control SFR

FIPSOC uses some Special Function Registers (SFR) of the internal memory map of the mP8051 for the memory configuration (used for programmable blocks interfaces) and general system control. These registers are described below:

Row Mask Register (h00 after Reset)

Address	Name	Byte	Description
\$F9,\$F8	ROW		Row Mask Register
	ROWL	\$F8	Row Mask Register Low Byte
	ROWH	\$F9	Row Mask Register High Byte

Column Mask Register (h00 after Reset)

Address	Name	Byte	Description
\$FB,\$FA	COL		Column Mask Register
	COLL	\$FA	Column Mask Register Low Byte
	COLH	\$FB	Column Mask Register High Byte

8051 Port 3.

Address	Name	Bit	Description
\$B0	PORTD		8051 Port 3
	NRD	PORTD.7	NRD for external memory. Must not be cleared
	NWR	PORTD.6	NWR for external memory. Must not be cleared
	PRTD5..2	5 thru 2	General Purpose
	TXD	PRTD.1	(Output) Serial port TX
	ETXD	PRTD.0	If cleared (=0), TX serial port is enabled.
	RX	PRTD.0	(Input) Serial Port RX

Note: Different registers are used for both read and write accesses. While writing, b11 - - - 10 must be fixed to keep communications through the serial port.

System Control Register 1 (h00 after Reset)

Address	Name	Bit	Description
\$FC	RG1		FIPSOCs Control Register 1
	CQDB1	RG1.7	Chip Quarter Data Buffer bit 1.
	CQDB0	RG1.6	Chip Quarter Data Buffer bit 0
	AMI	RG1.5	Analog Configuration memory mapped as Int. Mem. If 1, configuration memory is mapped in the Data Buffer locations of the Internal Memory (\$30-\$6F)
	LMI	RG1.4	LUT Data Memory mapped as Internal Mem. If 1, LUT Data memory is mapped in the Data Buffer locations of the Internal Memory (\$30-\$6F)
	HOI	RG1.3	Hardware Outputs mapped as Internal Memory. If 1, hardware outputs are mapped in the Data Buffer locations of the Internal Memory (\$30-\$6F). Use CQDB1 and CQDB0 to select the appropriate Quarter.
	HOE	RG1.2	Hardware Outputs mapped as External Memory
	CMI	RG1.1	Configuration Memory mapped as Internal Memory. If 1, configuration memory is mapped in the Data Buffer locations of the Internal Memory (\$30-\$6F)
	CME	RG1.0	Configuration Memory mapped as External Memory.

System Control Register 3 (h02 after Reset, 12x8 device)

Address	Name	Bit	Description
\$9B	RG3		FIPSOCs Control Register 3
		RG3.7	
		RG3.6	
		RG3.5	
		RG3.4	
		RG3.3	
	INTM	RG3.2	Interrupt mode. If 1, extended interrupt vectors mode is entered, if 0, basic 8051 interrupt mode is selected
	CM1	RG3.1	External Memory Compatible map bit 1
	CM0	RG3.0	External Memory Compatible map bit 0

System Control Register 2 (h00 after Reset)

Address	Name	Bit	Description
\$FD	RG2		FIPSOCs Control Register 2
	EPM	RG2.7	East Pads Mask bit.
	WPM	RG2.6	West Pads Mask bit
	NPM	RG2.5	North Pads Mask bit
	SPM	RG2.4	South Pads Mask bit.
	HOA1	RG2.3	Hardware Outputs Access Mode 1.
	HOA0	RG2.2	Hardware Outputs Access Mode 0.
	AME	RG2.1	Auxiliary Memory Enable. If this bit is set, the Aux. memory (256x8bits) is mapped at locations \$FF00-\$FFFF of both external data and program memories.
	EDMF	RG2.0	External Data Memory Function. If 1, external data memory is mapped in program memory locations. If this bit is set and CME = 1, the configuration memory of the Programmable Logic is used both for data and program memories.

Transfer Command Register (h2F after Reset)

Address	Name	Bit	Description
\$FE	RGTX		Transfer Register
	PLTB	RGTX.7	Programmable Logic Transfer bit. Writing to RGTX with this bit set produce a context transfer (set by RGTX.6) of the configuration in the DMCs
	CTXSB	RGTX.6	Context Select Bit. If this bit is set when writing to RGTX with PLTB = 1, context 1 is transferred to the configuration memory of the selected DMCs. If this bit is 0, context 0 is transferred.
	FCB	RGTX.5	Freezing Command Bit. A writing to RGTX with this bit set produce an start/stop action in the state machine of the clock generation block.
	FAB	RGTX.4	Freezing Action Bit. If this bit is set when writing to RGTX with FCB = 1, clocks stops by SW after CKCNT. If 0, clocks restarts.
		RGTX.3	
		RGTX.2	
		RGTX.1	
		RGTX.0	

4. PROGRAMMABLE BLOCKS & μ C INTERFACE

Configuration memories and outputs of the programmable blocks (PL and CAB) may be accessed through internal and external memory locations.

4.1. PL Subsystem Interface

Regular Configuration Memory: This memory may be mapped either through internal memory (data buffer access) or external memory. If a buffer access is done, row and column mask registers are needed, with the purpose of selecting the desired DMC(s), IO cell(s) or IIC (Internal Interface Cell) routing resources cell(s). Location \$30 through \$6F of the internal memory map will be used. If the external memory is used, each position of the *Regular Configuration Memory* of every DMC has its correspondence with one location on the external memory map.

4.1.1. Regular Configuration Memory

Regular Configuration Memory is used to configure the DMC. For this purpose, two different memory contexts have been included in the chip. A Transfer Command is needed for the configuration change. RGTX[7:6] is used: writing to this register with bit 7 set, data stored in the selected context of the *Regular Configuration Memory* will be transferred to the corresponding registers (context #0 is selected if bit 6 is cleared; otherwise, context #1 is selected). See PL Block Document for further information.

4.1.1.1. Buffer Access

Data buffer area is enabled by setting RG1[0] (SFR \$FC). Write and read operations affect to the selected DMCs marked by the column and row mask registers (*ROW* and *COL* registers), and to the IO and IIC cells routing resources cells selected by RG2[7:4] bits (east, west, north, south IO mask nibble), as shown in figure 4.1.

The buffer access area is organized in 2 blocks:

- ✓ \$30 to \$4F: 32 bytes map context #0 of the selected DMC,
- ✓ \$50 to \$6F: 32 bytes map context #1 of the selected DMC

A write operation on any of these locations writes data to all the DMCs (and IO and CAD-DMC cells) selected with the row and column mask registers and IO mask nibble.

A read operation should only be done with one DMC (or cell) selected; otherwise, the internal priority control would select only the one with the bigger column and row mask number (including IO mask bits as depicted in figure 4.1), or the first row/column if no one is selected.

The following accesses are not valid:

- ✓ write access with column register and west and east bits cleared (write is inhibit),
- ✓ write access with row register and north and south bits cleared (write is inhibit),
- ✓ read and write operations to physically non-exist DMC or cell; in this case, write operations will be inhibit and read operations will return random data.

4.1.1.2. External Memory Access

The *Regular Configuration Memory* is enabled when RG1[1]=1. The addresses space is divided into two areas: the lower half portion maps all the registers of context #0 and the upper locations map the configuration registers of context #1.

In both portions, the address decoding is done as follows:


- ✓ The 5 least significant bits address the 32 configuration registers of the corresponding context of the DMC,
- ✓ Every 32 locations the selected DMC is changed. The selection of the DMC is arranged, firstly, from east to west and, secondly, from south to north,
- ✓ The upper half maps context #1 with the same organization as the first portion.

The size and organization of the *Regular Configuration Memory* depend on the selected device model. Tables 4.1 shows the memory organization for the 8x12 models.

By default, the memory organization version mirrors the physical PL block model integrated in the device. However, different device models have been designed to have a compatible memory map. In fact, the logical memory organization and the physical implemented memory access have been separated. In this way, each FIPSOC model can be configured to have a memory organization equal to that of any other model. For example, the user can configure the 12x8 PL device to have the same memory map than the 16x16 model. This is a convenient way to develop an application using a big prototyping device (the 16x16 model) and produce it using a smaller device (12x8) with no changes at all. Table 4.2. shows the selection of the memory organization.

In the same way as data buffer access, a write and read access to a non-exist DMC has no sense.

IO cells and IICs routing resources cells cannot be accessed through external memory as only internal data buffer access is allowed.


Fig. 4.1: Data buffer access

Memory location	DMC selected		Description
	RCOL[15:0]	RROW[15:0]	
\$17C0 - \$17FF	h0080	h0080	(row 7, context 1)
...	(column 11)
\$0C00 - \$0C3F	h0001	h0001	(row 0, context 1)
\$0BC0 - \$0BFF	h0080	h0080	(row 7, context 0)
...	(column 11)
\$0200 - \$023F	h0001	h0002	(row 1, context 0)
\$01C0 - \$01FF	h0080	h0001	
...	
\$0040 - \$007F	h0002	h0001	
\$0000 - \$003F	h0001	h0001	(row 0, context 0)

Table 4.2: 12x8 model Configuration Memory Organization

RG2[5:4]	Memory Organization
00	16x16 model
01	16x12 model
10	12x8 model
11	8x8 model

Table 4.3: Logical Configuration Memory Organization selection

4.1.2. LUT Data Memory

This memory may only be mapped through the internal data buffer (setting RG1[4] bit). Read and write operations affect the selected DMC (using row and column mask register) like in the *Regular Configuration Memory* mode. Locations \$38 to \$3F map nibbles 0 to 7 of the Low Tile of the DMC(s) selected. Location \$40 to \$47 map the nibbles 0 to 7 of the High Tile of the DMC(s) selected. In both cases, the lowest nibble of the byte is used either in read or write access.

Location \$48 to \$4F map nibbles 0 to 7 of both Tiles, using the four most significant bits of each location for the nibble corresponding to the High Tile and the four least significant bits for the Low Tile. Locations \$30 to \$37 and \$50 to \$6F are not used.

Restrictions and priority features enumerated in the Configuration Memory section are also valid here.

IO cell and IICs routing resources cells have only configuration memory. Any write or read access with a IO mask bit set has no sense. Write operations will be inhibit and a read access will return random data.

4.1.3. Hardware Memory Area

This area may be accessed either through internal or external memory. Due to the fact that read and write accesses affect different signals, two modes are provided:

- **Hardware writing mode:** This mode is intended to provide a fast way to write in the flip-flops of the sequential part of the DMC in real time,
- **Hardware Probing mode:** This mode is intended to provide a fast way to probe hardware signals in real time, both sequential and combinational.

Four different accesses are allowed for both write and read operations (selected by RG2[3:2]). Table 4.6 lists these sub-modes.

RG2[3:2]	Hardware Writing	Hardware Probing
00	Single DMC context #0	Single DMC access (both contexts)
01	Single DMC context #1	
10	Horizontal 8-bit access	Horizontal 8-bit access
11	Vertical 8-bit access	Vertical 8-bit access

Table 4.6: Accesses allowed for both write and read operations

4.1.3.1. Data buffer Access

This access is enabled when RG1[2]=1. In both write and read modes only the DMCs of a Chip Quarter are mapped. RG1[7:6] are used for Chip Quarter selection (see tables 4.7 and figure 4.2).




Fig. 4.2: Chip Quarter distribution for the different models

RG2[7:6]	Quarter Selection (horizontal access)	Quarter Selection (vertical access)
00	South-East Quarter (Q0)	South-East Quarter (Q0)
01	South-West Quarter (Q1)	North-East Quarter (Q1)
10	North-East Quarter (Q2)	South-West Quarter (Q2)
11	North-West Quarter (Q3)	North-West Quarter (Q3)

Table 4.7: Logical Configuration Memory Organization selection

The different modes and sub-modes accesses allowed are described below:

- a) **Hardware Probing modes (read operations):** Sequential and combinational outputs are obtained. Different sub-modes bring as different organizations (see Table 4.9).

✓ *Single DMC access (RG[3:2]=0X):* Locations \$30 to \$6F map the outputs of the DMCs, one byte each DMC. The most significant nibble corresponds with the sequential output and the least one corresponds with the combinational output.

✓ *Horizontal 8-bit access (RG[3:2]=10):* Locations \$30 to \$4F (lower half) map the combinational outputs, two horizontally adjacent DMCs in each byte; locations \$50 to \$6F (upper half) map the sequential outputs, two horizontally adjacent DMCs in each byte.

✓ *Vertical 8-bit access (RG[3:2]=11):* The lower half portion maps the combinational outputs, two vertically adjacent DMCs in each byte; Locations of the upper half maps the sequential outputs, two vertically adjacent DMCs in each byte.

Table 4.9 and figure 4.3 show how simultaneous access to DMC pairs is performed.

- b) **Hardware Writing modes (write operations):** Flip-flops of the sequential part of the DMCs are written. Different accesses are allowed (see Table 4.9):

✓ *Single DMC context #0 access (RG[3:2]=00):* Each locations of the \$30 to \$6F area writes in context #0 of the flip-flops of one DMC. The least significant nibble of the locations is used in the operation.

✓ *Single DMC context #1 access (RG[3:2]=01):* Each locations of the \$30 to \$6F area writes in context #1 of the flip-flops of one DMC. The least significant nibble of the locations is used in the operation.

✓ *Horizontal 8-bit access (RG[3:2]=10):* Locations \$30 to \$4F write in context #0 of the flip-flops, two horizontally adjacent DMCs in each byte; locations \$50 to \$6F write in context

#1 of the flip-flops, two horizontally adjacent DMCs in each byte.

✓ *Vertical 8-bit access (RG[3:2]=11)*: Locations \$30 to \$4F write in context #0 of the flip-flops, two vertically adjacent DMCs in each byte; locations \$50 to \$6F write in context #1 of the flip-flops, two vertically adjacent DMCs in each byte.




Figure 4.3: Hardware Memory accesses mode

Only one DMC may be selected; column and row mask registers (and IO mask nibble) are ignored in Hardware memory modes.

Read and write operations to physically non-existent DMCs or cells have no sense; in this case, write operations will be inhibit and read operations will return random data.

4.1.3.2. External Memory

If RG1[3] is set, Hardware Memory is enabled. The area is located in the next 256 bytes after the *Regular Configuration Memory* locations (see table 3.1). All the DMC are mapped through the relative locations \$00 to \$FF. As in data buffer access, different modes and sub-modes are allowed:

a) Hardware Probing modes (read operations): Sequential and combinational outputs are obtained. Different sub-modes bring as different organizations (see Table 4.9).

✓ *Single DMC access (RG[3:2]=0X)*: Locations \$00 to \$FF map the outputs of the DMCs, one byte each DMC. The most significant nibble corresponds with the sequential output and the least one corresponds with the combinational output.

✓ *Horizontal 8-bit access (RG[3:2]=10)*: Locations \$00 to \$7F (lower half) map the combinational outputs, two horizontally adjacent DMCs in each byte; locations \$80 to \$FF (upper half) map the sequential outputs, two horizontally adjacent DMCs in each byte.

✓ *Vertical 8-bit access (RG[3:2]=11)*: The lower half portion maps the combinational outputs, two vertically adjacent DMCs in each byte; Locations of the upper half maps the sequential outputs, two vertically adjacent DMCs in each byte.

b) Hardware Writing modes (write operations): Flip-flops of the sequential part of the DMCs is written. Different accesses are allowed (see Table 4.9):

✓ *Single DMC context #0 access (RG[3:2]=00)*: Each locations of the \$00 to \$FF area writes in context #0 of the flip-flops of one DMC. The least significant nibble of the locations is used in the operation.

✓ *Single DMC context #1 access (RG[3:2]=01)*: Each locations of the \$00 to \$FF area writes in context #1 of the flip-flops of one DMC. The least significant nibble of the locations is used in the operation.

✓ *Horizontal 8-bit access (RG[3:2]=10)*: Locations \$00 to \$7F write in context #0 of the flip-flops, two horizontally adjacent DMCs in each byte; locations \$80 to \$FF write in context #1 of the flip-flops, two horizontally adjacent DMCs in each byte.

✓ *Vertical 8-bit access (RG[3:2]=11)*: Locations \$00 to \$7F write in context #0 of the flip-flops, two vertically adjacent DMCs in each byte; locations \$80 to \$FF write in context #1 of the flip-flops, two vertically adjacent DMCs in each byte.

Read and write operations to physically non-existent DMC or cell have no sense; in this case, write operations will be inhibit and read operations will return random data. Note that in all the FIPSOC models, 256 bytes are dedicated to map the Hardware Memory. Gaps exist in non-16x16 models.

4.2. CAB Subsystem Interface

CAB uses both data buffer and SFR maps for configure, control and data transfer.

4.2.1. Buffer Access

CAB Configuration Memory may only be mapped through the internal data buffer (if RG1[5] = 1). Configuration is done by writing in non-buffered conventional RAM memory. No multicontext is provided. Locations \$30 to \$6F constitute the whole CAB configuration memory.

Not all of the addresses are used. Unoccupied locations are reserved for future use.

4.2.2. Data transfer (through SFR area)

Data transfer and fast control (such as the start command and the end of conversion signals) are mapped in the SFR area.

Locations \$D8 through \$DF, \$E1 and \$FF are used (as shown in Table 4.8).

SFR	Register Name	Access mode
\$D8 to \$DB	<i>DANA1</i> to <i>DANA4</i>	Read and write
\$DC to \$DF	<i>DANA5</i> to <i>DANA8</i>	Read Only
\$E1	<i>ANAST</i> (mPCONV[3:0])	Read
	<i>ANAST</i> (mPDONE[3:0])	Write
\$FF	<i>outCOMP</i> [3:0]	Read Only

Table 4.8: Logical Configuration Memory Organization selection

✓ Input registers for their DACs are written by accessing to *DANA1* to *DANA4* SFRs.

✓ Output registers from the ADCs may be obtained by reading these four registers (*DANA1* to *DANA4*).

✓ *DANA5* to *DANA8* are read only registers and they are used in 4 input-multiplexed 10-bits ADC mode (see CAB document for detailed description).

✓ Outputs of the comparators section may be read by accessing to the least significant nibble of the read only *OutCOMP* SFR.

✓ *ANAST* registers has different functions: Writing on its bits, the corresponding ADC channel starts conversion. With a read access to the register, the end-of-conversion status is obtained. Only the least significant nibble is used.

See CAB Document for further information

Locations		Hardware Probing Mode		Hardware writing Mode	
Internal	External*	Horizontal 8-bit **	Vertical 8-bit ***	Horizontal 8-bit **	Vertical 8-bit ***
Q0, \$30	\$00	(1,0) & (0,0), comb	(0,1) & (0,0), comb	(1,0)&(0,0), context #0	(0,1)&(0,0) context #0
Q0, \$31	\$01	(3,0) & (2,0), comb	(0,3) & (0,2), comb	(3,0) & (2,0), ctx #0	(0,3) & (0,2), ctx #0
Q0, \$32	\$02	(5,0) & (4,0), comb	(0,5) & (0,4), comb	(5,0) & (4,0), ctx #0	(0,5) & (0,4), ctx #0
Q0, \$33	\$03	(7,0) & (5,0), comb	(0,7) & (0,6), comb	(7,0) & (5,0), ctx #0	(0,7) & (0,6), ctx #0
Q0, \$34	\$08	(1,1) & (0,1), comb	(1,1) & (1,0), comb	(1,1) & (0,1), ctx #0	(1,1) & (1,0), ctx #0
Q0, \$4F	\$3B	(7,7) & (6,7), comb	(7,7) & (7,6), comb	(7,7) & (6,7), ctx #0	(7,7) & (7,6), ctx #0
Q0, \$50	\$80	(1,0) & (0,0), seq	(0,1) & (0,0), seq	(1,0) & (0,0), ctx #1	(0,1) & (0,0), ctx #1
Q0, \$6F	\$BB	(7,7) & (6,7), seq	(7,7) & (7,6), seq	(7,7) & (6,7), ctx #1	(7,7) & (7,6), ctx #1
Q1, \$30	\$04	(9,0) & (8,0), comb	(1,8) & (0,8), comb	(9,0) & (8,0), ctx #0	(1,8) & (0,8), ctx #0
Q1, \$4F	\$3F	(15,7) & (14,7), comb	(7,15) & (6,15), comb	(15,7) & (14,7), ctx #0	(7,15) & (6,15), ctx #0
Q1, \$50	\$84	(9,0) & (8,0), seq	(1,8) & (0,8), seq	(9,0) & (8,0), ctx #1	(1,8) & (0,8), ctx #1
Q1, \$6F	\$BF	(15,7) & (14,7), seq	(7,15) & (6,15), seq	(15,7) & (14,7), ctx #1	(7,15) & (6,15), ctx #0
Q2, \$30	\$40	(1,8) & (0,8), comb	(9,0) & (8,0), comb	(1,8) & (0,8), ctx #0	(9,0) & (8,0), ctx #0
Q2, \$4F	\$7B	(7,15) & (6,15), comb	(15,7) & (14,7), comb	(7,15) & (6,15), ctx #0	(15,7) & (14,7), ctx #0
Q2, \$50	\$C0	(1,8) & (0,8), seq	(9,0) & (8,0), seq	(1,8) & (0,8), ctx #1	(9,0) & (8,0), ctx #1
Q2, \$6F	\$FB	(7,15) & (6,15), seq	(15,7) & (14,7), seq	(7,15) & (6,15), ctx #1	(15,7) & (14,7), ctx #1
Q3, \$30	\$44	(9,8)&(8,8), comb	(9,8)&(8,8), comb	(9,8)&(8,8), ctx #0	(9,8)&(8,8), ctx #0
Q3, \$4F	\$7F	(15,15)&(14,15) comb	(15,15)&(14,15) comb	(15,15)&(14,15) ctx #0	(15,15)&(14,15) ctx #0
Q3, \$50	\$C4	(9,0)&(8,15), seq	(9,0)&(8,15), seq	(9,0)&(8,15), ctx #1	(9,0)&(8,15), ctx #1
Q3, \$6F	\$FF	(15,15)&(14,15), seq	(15,15)&(14,15), seq	(15,15)&(14,15) ctx #1	(15,15)&(14,15), ctx #1
* Memory Locations are relative (absolute values depend on map organization version)					
** DMCs are arranged to, first, from East to West and, secondly, from South to North of die size (8x8 for each Quarter in internal access and 16x16 for external access)					
*** DMCs are arranged to, first, from South to North and, secondly, from East to West of die size (8x8 for each Quarter in internal access and 16x16 for external access)					

Table 4.9: DMC association in vertical and horizontal accesses